EXTEND THE LIFE OF YOUR PLUGS!

THE LANSAS PROTECTIVE SLEEVES not only protect the plug while being moved around the jobsite, but offers further protection by remaining on the plug while inflated in the pipeline. These sleeves help eliminate damage from pipeline debris, degraded pipe, barnacles, and more. Lansas Protective Sleeves can easily be repaired at the factory.



PROTECTIVE SLEEVES		
PART NUMBER	FITS PLUGS WITH NOTED PART NUMBERS	WEIGHT
069-610	050-610, 051-610	2.5 lbs. (1.13 kg)
069-610FT	093-610	2.5 lbs. (1.13 kg)
069-812	050-812, 051-812	3.0 lbs. (1.36 kg)
069-812FT	092-812, 093-812, 094-812	3.0 lbs. (1.36 kg)
069-1016	050-1016, 051-1016	6.0 lbs. (2.72 kg)
069-1016 FT	094-1016, 096-1016, 096-812	6.0 lbs. (2.72 kg)
069-1218	050-1218, 051-1218	10.0 lbs. (4.54 kg)
069-1218FT	094-1218, 096-1218, 098-1218	10.0 lbs. (4.54 kg)
069-1224	050-1224, 051-1224	14.0 lbs. (6.35 kg)
069-1224FT	094-1221, 096-1224, 098-1224	14.0 lbs. (6.35 kg)
069-1530	050-1530, 051-1530, 094-1530	21.0 lbs. (9.53 kg)
069-1530FT	094-1530Н, 096-1530, 098-1530	21.0 lbs. (9.53 kg)
069-2036	050-2036, 051-2036, 094-2036	28.0 lbs. (12.70 kg)
069-2036FT	094-2036Н, 096-2036, 098-2036	28.0 lbs. (12.70 kg)
069-2448	050-2448, 051-2448, 094-2448, 096-2448, 098-2448	53.0 lbs. (24.04 kg)
069-3660	050-3660, 051-3660, 094-3660, 096-3660, 098-3660	78.0 lbs. (35.38 kg)
069-4278	050-4278, 051-4278, 094-4278, 096-4278, 098-4278	93.0 lbs. (42.18 kg)
069-4872	050-4872, 051-4872, 094-4872, 096-4872, 098-4872	89.0 lbs. (40.37 kg)
069-6096	050-6096, 051-6096, 094-6096, 096-6096, 098-6096	166.0 lbs. (75.30 kg)
		1/3.30 Kg)

FT Sleeves for Flow-Thru™ Plugs Custom Sleeves Available